


## SPREADER BEAMS

Telescoping Adjustable

### ADJUSTABLE SPREAD TELESCOPING BEAMS - LARGE CAPACITY SHACKLE END

- Manufactured to exceed all ASME B30.20 and OSHA regulations.
- Painted safety yellow for increased visibility.
- ALL Spreader Beams shipped with proof load certification paperwork.
- Durable construction ideally suited to jobsite or warehouse use.
- Made in U.S.A.
- Custom designs available - call for engineering.
- ALL lifting equipment individually proof loaded per OSHA requirements.
- Minimum horizontal top rigging angle of 45°
- Ideally suited for adding stability to critical lifts.
- Beam only. Shackles supplied by others.

 Prop 65 – See Page 102



SHOWN WITH OPTIONAL TOP RIGGING & SHACKLES

TELESCOPING ADJUSTABLE LARGE CAPACITY SHACKLE END SPREADER BEAMS						
Working Load Limit in Pounds*	Shackle Size	Model Number Headroom (in) Weight (lbs)	Outside Spread (L) in Feet*			
			Min Max 5'6" - 7'	Min Max 7 - 10	Min Max 10 - 14	Min Max 14 - 20
40,000	1-1/2" Top 1-1/2" Bottom	<b>Part Number</b>	<b>20127</b>	<b>20126</b>	<b>20125</b>	<b>20124</b>
		HR =	7.6	7.6	7.6	7.6
		LBS =	340	410	560	760
60,000	1-3/4" Top 1-3/4" Bottom	<b>Part Number</b>	<b>20132</b>	<b>20131</b>	<b>20130</b>	<b>20129</b>
		HR =	7.1	7.1	7.1	7.1
		LBS =	395	490	660	890
80,000	2" Top 2" Bottom	<b>Part Number</b>	<b>20137</b>	<b>20136</b>	<b>20135</b>	<b>20134</b>
		HR =	9.3	9.3	9.3	9.3
		LBS =	575	700	950	1,250
100,000	2" Top 2" Bottom	<b>Part Number</b>	<b>20142</b>	<b>20141</b>	<b>20140</b>	<b>20139</b>
		HR =	9.3	9.3	9.3	9.3
		LBS =	575	700	950	1,250

OPTIONAL TOP RIGGING						
Working Load Limit in Pounds*	Part Name		Part Number	Part Number	Part Number	Part Number
40,000	<b>Adjustable Spreader</b>		<b>20127</b>	<b>20126</b>	<b>20125</b>	<b>20124</b>
	Wire Rope		23421	23422	23423	23424
	Round Sling Bridle		23433	23434	23435	23436
60,000	<b>Adjustable Spreader</b>		<b>20132</b>	<b>20131</b>	<b>20130</b>	<b>20129</b>
	Wire Rope		23425	23426	23427	23428
	Round Sling Bridle		23437	23438	23439	23440
80,000	<b>Adjustable Spreader</b>		<b>20137</b>	<b>20136</b>	<b>20135</b>	<b>20134</b>
	Wire Rope		23430	23430	23431	23432
	Round Sling Bridle		23441	23442	23443	23444
100,000	<b>Adjustable Spreader</b>		<b>20142</b>	<b>20141</b>	<b>20140</b>	<b>20139</b>
	Wire Rope		23430	23430	23431	23432
	Round Sling Bridle		23441	23442	23443	23444

\*Minimum horizontal top rigging angle is 45° on all fixed and adjustable spreaders. M&W recommends a minimum horizontal top rigging angle of 60°. Adjustable on 6" increments.