


## PLATE CLAMPS

Plate Clamp - Hinged

### PLATE CLAMP – HINGED



#### HINGED

WLL (LBS)	Part #	A-Jaw Opening	B	C	D	E	F	G	H	J	K	Weight in Pounds
0-1,100	21718	0-0.5	1.64	6.31	10.6	1.63	3.81	0.5	1.45	0.5	2.5	6.5
	21719	0.5-1.0	1.64	6.31	10.6	1.63	4.31	0.5	1.45	0.5	2.5	6.8
	21720	1.0-1.5	1.64	6.31	10.6	1.63	4.81	0.5	1.45	0.5	2.5	7.1
0-2,200	21854	0-0.75	1.92	8.06	14.7	2.13	5.5	0.5	1.71	0.75	2.75	11.7
	21855	0.75-1.5	1.92	8.06	14.7	2.13	6.25	0.5	1.71	0.75	2.75	12.3
	21856	1.5-2.25	1.92	8.06	14.7	2.13	7	0.5	1.71	0.75	2.75	13
0-4,400	21915	0-1.0	2.41	9.37	18.3	2.38	7	0.5	2.21	0.75	3.29	22.8
	21916	1.0-2.0	2.41	9.37	18.3	2.38	8	0.5	2.21	0.75	3.29	24
	21917	2.0-3.0	2.41	9.37	18.3	2.38	9	0.5	2.21	0.75	3.29	26